



PINNACLE SELECT OUTSWING (Wood Interior)


PART LIST






















PINNACLE SELECT OUTSWING (Wood Interior)

IMAGE	ITEM #	DESCRIPTION	TYPE	PART #
	1	ARIA HANDLE (ACTIVE PANEL)	BLACK BRONZE WHITE SATIN CHROME	48000 48001 48002 48003
		ACACIA HANDLE (ACTIVE PANEL)	BLACK BRONZE WHITE SATIN CHROME	48004 48005 48006 48007
		SUMMIT HANDLE (ACTIVE PANEL)	BLACK BRONZE WHITE SATIN CHROME	48008 48009 48010 48011
	2	ARIA HANDLE (INACTIVE PANEL)	BLACK BRONZE WHITE SATIN CHROME	48012 48013 48014 48015
		ACACIA HANDLE (INACTIVE PANEL)	BLACK BRONZE WHITE SATIN CHROME	48016 48017 48018 48019
		SUMMIT HANDLE (INACTIVE PANEL)	BLACK BRONZE WHITE SATIN CHROME	48020 48021 48022 48023
	3	LOCKING MECHANISM (ACTIVE PANEL)	3-POINT LOCK 4-POINT LOCK	48024 48025
	4	LOCKING MECHANISM (INACTIVE PANEL)	2-POINT LOCK	48026
	5	PANEL HINGE RECEIVER	STAINLESS STEEL	48027
	6	SIDE FRAME HINGE RECEIVER	STAINLESS STEEL	48028

PINNACLE SELECT OUTSWING (Wood Interior)

IMAGE	ITEM #	DESCRIPTION	TYPE	PART #
	7	BI-PART STRIKE PLATE	ALUM. PC TO MATCH UNIT	48029
	8	SIDE FRAME STRIKE PLATE	ALUM. PC TO MATCH UNIT	48030
	9	HINGE	DARK BRONZE SATIN CHROME	48031 48032
	10	PANEL SIDE COVER	ALUM. PC TO MATCH UNIT	48033
	11	BI-PART GASKET	BLACK	48034
	12	BI-PART GASKET	BLACK	48035
	13	PANEL SIDE GASKET	BLACK	48037
	14	FRAME GASKET	BLACK	48038
	15	BI-PART FELT BRUSH	BLACK	48043
	16	ACTIVE PANEL BIPART CLIP	ALUM. PC TO MATCH UNIT	48041
	17	INACTIVE PANEL BIPART CLIP	ALUM. PC TO MATCH UNIT	48042